INDUCTION RANGES QUICK START GUIDE

HOW IT WORKS

1. To turn on the range, rotate the knob for the desired hob.
2. Place an induction-compatible pan on the hob.
3. Rotate the knob directly upward to turn it off.



Four Hob

OPERATOR NOTES

- When the range is turned on without a pan on the hob, the display flashes
- When an induction pan is placed on the hob, the display stops flashing and indicates the selected power level
- If no pan is detected for 5 minutes, the range enters sleep mode, and the LEDs display a moving pattern
- Turn a control knob to wake a range in sleep mode



Six Hob

DAILY CLEANING

1. Turn all knobs to the OFF position.
2. Wipe the outside with a suitable cleaner, rinse, and then dry.
3. Clean the filter if needed.
4. If the filter becomes dirty, remove and clean:

   ***Note**: Monthly cleaning is recommended.*

   a. Remove the thumbscrew.
   b. Pull the filter guard forward to access the air filters.
   c. Lift the filter, slide it forward, and remove it.
   d. Wash the filter with cold water or in a dishwasher.
   e. Ensure the filter is completely dry before reinstalling.

      ***Note**: The filter must be completely dry before reinstallation to avoid damage or operational issues. Never reinstall a wet filter into the unit*

FOUR HOB

SIX HOB

Scan to view complete instructions and unit specifications

VIC46-QSG-A / August 2026

2801 Trade Center Drive | Carrollton, TX 75007
+1 214-379-6000 | cooktek.com